XBA-NC85D

お買い上げいただきありがとうございます。

と製品の取り扱いかたを示しています。 この取扱説明書

をよくお読みのうえ、製品を安全にお使いください。お

読みになったあとは、いつでも見られるところに必ず保

△警告 安全のために

ソニー製品は安全に充分配慮して設計されています。

しかし、電気製品はすべて、まちがった使いかたをすると、

火災や感電などにより人身事故になることがあり危険です。

4-289-019-**12**(1)

4 2 8 9 0 1 9 1 2 * (1)

©2011 Sony Corporation Printed in Malaysia

USB 充電 AC アダプターを用いて充電するときは、必ず「推

奨アクセサリー」に記載の AC-U501AD (別売)、

AC-UP100 (別売) を使用してください。

分解しない

故障や感電の原因となります。内部の点検および修理は ソニーの相談窓口またはお買い上げ店、ソニーサービス 窓口にご依頼ください。





火のそばや炎天下などで充電したり放置しな



自動車やバイク、自転車などの運転中に、ヘッドホンは

絶対に使わないでください。交通事故の原因となります。

周囲の音が聞こえないと危険な場所では使用

歩行中でも音量を上げすぎるとまわりの音が聞こえなく

また、このヘッドホンは周囲の音を低減するタイプです

踏み切りや横断歩道、駅のホーム、車の通る道、工事現

場など、周囲の音が聞こえないと危険な場所では使わな

ので、警告音なども聞こえにくくなります。

いでください。





この表示の注意事項を守らないと、けがをしたり周辺

事故を防ぐために次のことを必ずお守りください。 安全のための注意事項を守る

この「安全のために」の注意事項をよくお読みください 定期的に点検する

1年に一度は、付属の USB 充電器のプラグ部にほこりが

たまっていないか、故障したまま使用していないか、な どを点検してください。

動作がおかしくなったり、本機が破損していることに気づ

いたら、すぐにお買い上げ店またはソニーサービス窓口に 修理をご依頼ください。



製品登録のおすすめ

http://www.sony.co.jp/avp-regi/

携帯電話から

携帯電話·PHS·一部のIP電話·· 0466-31-2511

携帯電話・PHS・一部のIP電話・・0466-31-2531

※取扱説明書・リモコン等の購入相談はこちらへお問い合わせください。

パソコンから

使い方相談窓口

フリーダイヤル・・

FAX (共通) 0120-333-389

|**|亜歐ののすすの** |一は、製品をご購入いただいたお客様のサポートの充実を図るため、

2次元コード対応のカメラつき携帯電話の読み取り機能で

ソニー株式会社 〒108-0075 東京都港区港南1-7-

製品登録をお願いしております。詳しくはウェブ上の案内をご覧ください

ttp://reg.msc.m.sony.jp/avp/

よくあるお問い合わせ、窓口受付時間などは ホームページをご活用ください。 http://www.sony.co.jp/support

0120-222-330

電器をパソコンなどか らはずし、ヘッドホン

● 電源を切る ★ ② 充電中の場合はUSB充 をUSB充電器からはず 3 お客様ご相談センター またはお買い上げ店、

電気製品は安全のための注意事項を守らないと、火災や「食事性」 ないと、火災や人身事故になることがあ この取扱説明書には、事故を防ぐための重要な注意事項

この表示の注意事項を守らないと、火災や人身事故の

原因となります。

注意を促す記号

行為を禁止する記号



付属の USB 充電器以外を使わない

充電するときは、必ず付属の USB 充電器を使用してくだ 破裂や電池の液漏れ、過熱などにより、火災やけが、周 囲の汚損の原因となります。





付属の USB 充電器の充電ジャックに他の ヘッドホンや電子機器を接続しない

付属の USB 充電器は本機専用です。過熱・故障などによ り火災やけがの原因になります。

警告表示の意味

取扱説明書および製品では、次のような表示をしてい ます。表示の内容をよく理解してから本文をお読みく

<u>⚠</u> 危険

この表示の注意事項を守らないと、火災、感電、破裂 などにより死亡や大けがなどの人身事故が生じます。

の家財に損害を与えたりすることがあります。









水や異物が入ると火災や感電の原因になります。万一、水 や異物が入ったときは、すぐに使用を中止し、お買い上 げ店またはソニーサービス窓口にご相談ください。





ぬれた手で USB 充電器をさわらない 感電の原因となります。





本体や USB 充電器を布団などでおおった状 態で使わない

熱がこもってケースが変形したり、火災の原因となるこ





大音量で長時間続けて聞きすぎない

耳を刺激するような大きな音量で長時間続けて聞くと、聴 力に悪い影響を与えることがあります。 耳を守るため、音量を上げすぎないようにご注意ください。







推奨以外の USB 充電 AC アダプターを使わ はじめからボリュームを上げすぎない

突然大きな音が出て耳をいためることがあります。接続 した機器のボリュームは徐々に上げましょう。特に、MD. CD や DAT など、雑音の少ないデジタル機器を聞くとき にはご注意ください。



肌に合わないと感じたときは、使わない 肌に合わないと感じたときは早めに使用を中止して、医

師またはソニーの相談窓口、お買い上げ店にご相談くだ





• 本機を使用中に気分が悪くなった場合は、すぐに本機の 使用を中止してくださし

• このヘッドホンは、密閉度を高めていますので、強く押 された場合、鼓膜などを痛める危険があります。他の人 と強く接触したり、ボールなどが飛んでくるような場所 では使用しないでください

◆イヤーピースはしっかり取り付けてください。イヤー ピースがはずれて耳に残ると、けがや病気の原因となる ことがあります。

電池についての 安全上のご注意

液漏れ・破裂・発熱・発火・ 誤飲による大けがゃ失明を避けるた め、下記の注意事項を必ずお守りください。

危険

充電式電池が液漏れしたとき 充電式電池の液が漏れたときは素手で液をさわ


液が本体内部に残ることがあるため、ソニーの相談窓 口またはソニーサービス窓口にご相談ください。 液が目に入ったときは、失明の原因になることがある ので目をこすらず、すぐに水道水などのきれいな水で 充分洗い、ただちに医師の治療を受けてください。 液が身体や衣服についたときも、やけどやけがの原因 になるので、すぐにきれいな水で洗い流し、皮膚に炎 症やけがの症状があるときには医師に相談してくださ

| _____ 警告 | 充電式電池について ● 付属の USB 充電器以外で充電しない。

● 火の中に入れない。分解、加熱しない • 火のそばや直射日光の当たるところ・炎天下の車中など、


高温の場所で使用・保管・放置しない。 • 液漏れした電池は使わない。

日本国内での充電式電池の廃棄



クルできます。この充電式電池の取り外し はお客様自身では行わず、「お客様ご相談も ンター」にご相談ください。(「お客様ご相 Ni-MH 談センター」の連絡先は左下に記載されて います。)

• コード途中のコントロールボックスを無くしたボックスレス



主な特長

• 新開発のバランスド・アーマチュア・ドライバーユニット および高性能 MEMS マイクロホン採用

- 独自開発、DNC ソフトウェアエンジン搭載 高精度なキャンセル信号生成により、約 97.5%* の卓越 した騒音低減を実現。
- 充電中はヘッドホンの電源を入れることができません。 ● 雷源コンセントから充電するときは、「推奨アクセサリー」に記 長時間スタミナ フル充電で約 20 時間のリスニングを実現。長距離フライ
 - 載の USB 充電 AC 電源アダプター AC-U501AD (別売)、バッテ リー内蔵 USB AC チャージャー AC-UP100 (別売) をお使いください。詳しくは、アダプターに付属の取扱説明書をご覧くださ
- フルオート AI ノイズキャンセリング機能搭載 ● ヘッドホンに異常がある場合、充電は開始されずに USB 充電器 周囲の騒音を常に分析し、最適なノイズキャンセリング の充電ランプが点滅します。この場合は、ヘッドホンと充電器を
- つないだ機器からはずし、お買い上げ店またはソニーの相談窓口 • デジタルイコライザー 理想的な周波数特性を実現、高音質での音楽再生が可能。 • ノイズアイソレーションイヤーピース
- 充雷は0℃~40℃の環境で行ってください。この範囲を超える 遮音性を向上させるノイズアイソレーションイヤーピース と、満充電されない場合があります。 充電は、ヘッドホンを耳からはずしてから行ってください。 ヘッドホンのプラグを抜くときは、グリップ部分を持って引き抜


なります。

- 専用 USB 充電器 持ち運びに便利な小型の専用 USB 充電器付属。 • 長い間使わなかったときは、充電池の持続時間が短くなることが 当社規定の航空機シミュレートノイズ下における、ノイズキャン
- セリングモード A 時と、ヘッドホンの非装着時との比較による

まず充電を!

本機には、充電式ニッケル水素電池が内蔵されています。 内蔵の電池は、工場出荷時点からお客様がお買い上げにな るまでの期間に自己放電によりある程度消耗しています。お 使いになる前に、必ず充電を行ってください。充電のしかた は、「ヘッドホンを充電する」をご覧ください。

各部のなまえ



- ヘッドホン本体 **1** マイク部
- 2 イヤーピース
- ③ 電源ランプ (赤)
- 本機の動作状態を表示します。 **4** (電源) ボタン
- 5 ステレオミニプラグ(充電プラグ)


専用 USB 充電器

- 6 キャップ
- 7 USB プラグ 8 充電ランプ (オレンジ)
- 充電の状態を表示します。 9 充電ジャック

ヘッドホンを充電する

本機は充電式ニッケル水素電池を内蔵しています。充電し てからお使いください。

- **1** 接続するパソコンなどの電源を入れる。
- **2** 専用 USB 充電器のキャップをはずし、パソコンな どにつなぐ。
- 3 ヘッドホンのプラグを、USB 充電器の充電ジャッ クの形に合わせて奥まで差し込む。 充電ランプがオレンジ色に点灯し、充電が始まります。



4 充電ランプが消灯したら、ヘッドホンのプラグを USB 充電器からはずす。

5 USB 充電器をはずし、キャップを取り付ける。

充電時間の目安と持続時間

音楽を聞く 付属の充電器は、ヘッドホンに内蔵された電池の残量によっ て充電時間が約15分から約4時間かかります。

充電時間 持続時間 *

電源は自動的に切れます。

*¹ 1 kHz、音圧レベル 90dB 出力時 *2 電池残量がない状態から、満充電するのにかかる時間 3 周囲の温度や使用状態により、上記の持続時間と異なる場合があ

ヘッドホンの電源が入っているときに充電すると、ヘッドホンの

いてください。コードを引っ張ると断線のおそれがあります。

あります。何回か充放電を繰り返すと、充分に充電できるように

• 長期にわたって保存する場合は、高温の場所は避けて保存してく

池の過放電防止のため、年 1 回程度の充電を行ってください。

USB 充電に対応しているパソコンの推奨環境については、「USB

• 延長コードをご使用になると充電を開始しません。本機のプラグ

イヤーピースの正しい装着方法

イヤーピースが耳にフィットしていないと、適切なノイズキャ

キャンセリング効果と、より良い音質を楽しんでいただくた

い位置に調整するなど、ぴったり耳に装着させるようにして

めには、イヤーピースのサイズを交換したり、おさまりの良

お買い上げ時には、M サイズが装着されています。サイズ

が耳に合わないと感じたときは、付属のLサイズやSサイ

イヤーピースがはずれて耳に残らないよう、イヤーピースを

交換する際には、ヘッドホンにしっかり取り付けてください。

ヘッドホンを片手で押さえ、もう一方の手でイヤーピースを

イヤーピースが滑りやすくはずしにくいときは、乾いた柔らかい布

ヘッドホンの突起部分が完全に隠れるまで、イヤーピースの

トすることにより効果を発揮します。長時間の使用により、違和

たり引っ張ったりしないでください。ウレタンが破れたり、イヤー

• 低反撥ウレタン素材は、長期の使用・保存により劣化します。反

撥力が失われて硬くなってくると、ノイズアイソレーションイ

ノイズアイソレーションイヤーピースは洗わないでください。ま

と、汗などは充分に乾燥させて、低反撥ウレタン内部に水分が残

らないようにしてください。早期劣化の原因となるおそれがあり

ヤーピースとして機能しなくなるおそれがあります。

『一スから分離したりすると、元に戻らず、ノイズアイソレーショ

感のある場合には、小休止を設けることをおすすめします。

ンイヤーピースとして機能しなくなります。

● 低反撥ウレタン素材は非常に柔らかいため、ウレタンだけを持っ

ンセリング効果が得られない場合があります。快適なノイズ

充電のパソコン推奨環境 | をご覧ください。

を直接充電器に接続してください。

ズに交換してください。

(内側の色)

断面図

ヴ ヒント

イヤーピースのサイズ

イヤーピースをはずすときは


軸ごとねじりながらはずします。

でくるむとはずしやすくなります。

着色部分を押し込んでください。

イヤーピースを付けるときは

ださい。また、1年以上の長期にわたって保存する場合は、充電



左右識別用突起

1 聞きたい AV 機器を接続する。

2 ヘッドホンを付ける。

® の印のついた方を右耳に、© (左右識別用の突起が あります)の印のついた方を左耳に付けてください。 イヤーピースは耳の穴を密閉するように、差し込んでく

イヤーピースが耳の穴にフィットしていないと、ノイズキャン セリング効果が得られませんので、イヤーピースはおさまりの

良い位置に調整をして、ぴったりと耳に装着させるようにして **3** (電源) ボタンを 2 秒以上押す。

ヘッドホンからビープ音が聞こえて、電源ランプが点滅 します。

電源を入れるとサーッという音が聞こえますが、これはノイズ

キャンセリング機能の動作音で故障ではありません。 4 接続した AV 機器を再生する。 お使いになったあとは

1 ① (電源) ボタンを 2 秒以上押す。 ヘッドホンからビープ音が聞こえて電源ランプが点灯し 電源が切れます。

2 ヘッドホンをゆっくりと耳から取りはずす。

● 本機の電源が入っていないと、AV 機器の再生音は聞こえません。 • 本機は密閉度を高めていますので、強く押された場合や急に耳か

らはずした場合、鼓膜などを痛める危険があります。 充電池残量の目安

本機の電源を切ったときに聞こえるビープ音の回数で充電 池の残量を確認できます。詳しくは、「ビープ音とランプ表

示の意味」をご覧ください。 充電式電池の残量がなくなると、ビープ音が 2 秒間鳴って 電源ランプが約30秒間点滅したあとに、本機の電源が切れ

フルオート AI ノイズキャンセリングについ

フルオート AI ノイズキャンセリングはノイズキャンセリング

モードを自動的に選択する機能です。 本機の電源を入れると、まず NC モード B で動作を開始し ます。そのあとは周囲の環境音を常に解析し、環境音の変 化に追従しながらその場に最も効果的なノイズキャンセリン グモードへ自動的に移行します。

ノイズキャンセリングモードの種類

電源ランプの点滅回数で、現在設定されているモードを確 認できます。詳しくは、「ビープ音とランプ表示の意味」を

NC モード A 主に航空機内の騒音を効果的に低減

NC モード B 主にバス・電車の騒音を効果的に低減 主にオフィス・勉強部屋など、OA 機器・空調機器の騒音を

効果的に低減

騒音の性質は、時を追って変化していきます。 本機は、その場の騒音に最適なノイズキャンセリングモードを自動 的に選択します。

コード長アジャスターの使いかた

図のようにコードを巻きつけて長さを調節できます。 (巻きつける長さは 40 cm までを目安に調節してください。 それ以上巻きつけるとコードがはずれやすくなります。)

1 コードを巻きつける。 **2** みぞに差し込んで固定する。

プラグやコード分岐部分を巻きつけないようにしてください。負担 がかかりやすく断線につながるおそれがあります。

1 クリップが開かないように持ちながらレバーを軽

• レバーが上がりきった状態と下がっている状態では、みぞにコー

コードを突起部に引っかけたり、みぞへ無理に押し込んだりしな

• コードを取り付けた状態のまま、クリップの位置を変更しないで

2 レバー下部のみぞにコードを入れる。

いでください。断線するおそれがあります。

航空機内で使用するときのご注意

• 付属のプラグアダプターは、航空機のデュアルジャック語

デュアルジャック ステレオミニジャック

• 航空機内で電子機器の使用が禁止されている場合や、機

止されている場合は、本機を使用しないでください。

本機を使用しないときはヘッドホンを耳からはずしてくだ

本機をキャリングケースに収納するときは、コードを束ねて

キャリングケースの使いかた

ビープ音とランプ表示の意味

雷源ランプ

充電ランプ

点灯

消灯

早く点滅

充電状態: USB 充電器の充電ランプでお知らせ

5 秒おきに 1 回点滅

5 秒おきに 2 回点滅

5 秒おきに 3 回点滅

ンの電源ランプでお知らせ

動作中のモード

NC モード A 動作中

NC モード B 動作中

NC モード C 動作中

充電状態

充電中

充電終了

から収納してください。

内の音楽サービスを個人のヘッドホンで利用することが禁

たはステレオミニジャックに接続することができます。

ください。断線するおそれがあります。

クリップの使いかた

ドを入れることができません。

音が出ない。

- → ヘッドホンの電源を入れる。
- → ヘッドホンの充電池の残量を確認する → ヘッドホンと AV 機器との接続を確認する。

→ ヘッドホンに接続した AV 機器の電源が入っているか確認する。 → 接続した AV 機器の音量を上げる。 音圧感度:

電源が入らない。 → ヘッドホンを充電する

音がひずむ。

→ ヘッドホンを充電する。

→ ヘッドホンを充電する。

相談窓口にご相談ください。

使用上のご注意

操作できない。

→ 接続した AV 機器の音量を下げる。

→ 充電中はヘッドホンの電源が入りません

- 相談窓口にご相談ください → 充電中はヘッドホンの電源が入りません
- 充電しても電源が入らないときは充電池の劣化などの異常があ る場合があります。この場合は、お買い上げ店またはソニーの

ヘッドホンを USB 充電器からはずし、電源を入れてください。

推奨アクセサリーに記載の USB 電源アダプターを使用してく

- 充電できない。 → 充電ランブが点灯しているか確認する。 ヘッドホンのブラグが USB 充電器のジャックにしっかり奥ま
- で挿入されていることを確認してください。 ➡ USB 充電器がパソコンなどにしっかり接続されているか確認す
- → パソコンなどの電源が入っているか確認する。 → パソコンがスタンバイ(スリープ)、休止状態に入っていないこ 保証書(1) とを確認する。
- がっているか確認する。 推奨アクセサリー *4 → 推奨外の USB 電源アダプターを使用している。
- → 充電ランプが点滅している場合は、ヘッドホンの異常が考えら *1 当社測定法による れます。接続機器からはずして、お買い上げ店またはソニー相 談窓口にご相談ください。

USB 充電器がパソコンに認識されない。 騒音低減に相当します。 3 機内の音楽サービスによっては、対応ができない場合があります。 → USB 充電器がパソコンなどにしっかり接続されているか確認す

- ➡ USB 充電器を一度はずしてから、接続しなおす。
- → USB 充電器とパソコンが USB ハブなどを経由せずに直接つな 以下の OS が標準インストールされており、USB ポートが標準装備 がっているか確認する。 ➡ 接続しているパソコンの USB ポートに問題がある可能性があ
- パソコンに別の USB ポートがあれば、そのポートに接続しな

- Windows® をお使いの場合 → 上記に当てはまらない場合は、USB接続をしなおす。

※ 64 ビット版含む Windows Vista® (Service Pack 2 以降)

- (Home Basic / Home Premium / Business / Ultimate ※ 64 ビット版含む
- Media Center Edition 2005) - Macintosh をお使いの場合

式会社の登録商標です。

本機は、ノイズキャンセリング機能を搭載したヘッドホンで

ヘッドホンを USB 充電器からはずして操作してください。

充電しても電源が入らないときは充電池の劣化などの異常があ

る場合があります。この場合は、お買い上げ店またはソニーの

ノイズキャンセリング機能とは

外部の環境ノイズ(乗り物内の騒音や室内の空調音など) と逆位相の音を出すことで環境ノイズが低減して聞こえる機

- 静かな場所やノイズの種類によっては、ノイズキャンセリ ング効果が感じられない、またはノイズが大きくなると感 じられる場合があります。
- ヘッドホンのマイク部を手などで覆わないでください。ノ イズキャンセリング効果が得られなくなる場合がありま
- ヘッドホンのつけかたによっては、ノイズキャンセリング効 果が減少することがあります。
- 落としたりぶつけたりなどの強いショックを与えないでくだ

• 湿気やほこり、油煙、湯気の多い場所や直射日光のあた る場所には置かないでください。故障の原因となります • 常に良い音でお聞きいただくために、プラグをときどき柔 らかい布でからぶきし、清潔に保ってください。 • 汚れは、乾いた柔らかい布でふき取ってください。特に

- プラグ部分を汚れたままにしておくと、音質が悪くなった り、音がとぎれたりすることがあります。 • イヤーピースは長期の使用・保存により劣化するおそれ があります。
- イヤーピースは、誤飲や窒息などの危険がありますので 小さなお子様の手の届かないところに保管してください。 • 直射日光が長時間当たる場所や、暖房器具の近く、窓を しめきった自動車内などの温度が非常に高い(60℃以上 ところや、湿気の多いところでのご使用、放置は避けてく

静電気に関するご注意

くことにより影響が軽減されます。

空気が乾燥する時期にノイズが聞こえる、音がとぎれる、耳 にピリピリと痛みを感じることなどがありますが、これはヘッ ドホンの故障ではなく人体に蓄積される静電気によるもので

静電気の発生しにくい天然素材の衣服を身につけていただ

イヤーピースは消耗品です。紛失・破損した場合は、お 買い上げ店、またはソニーの相談窓口にご相談ください。

万一故障した場合や異常、不具合が起きたときは、内部 を開けずにソニーの相談窓口またはお買い上げ店、ソニー サービス窓口にお問い合わせください。

故障とお考えになる前に

密閉バランスド・アーマチュア型 ドライバーユニット:

バランスド・アーマチュア

インピーダンス: 820 Ω (1 kHz にて) 106 dB (150 mV 入力時) **再生周波数帯域**: 5 Hz ~ 20.000 Hz

主な仕様

総騒音抑制量 (TNSR)*

約 15 m OFC リッツ線 ネックチェーン 金メッキL型ステレオミニプラグ 内蔵充電式ニッケル水素電池

約6g(コード含まず)

同梱物

ヘッドホン 専用 USB 充電器 (航空機用プラグアダプター(1)*

- ノイズアイソレーションイヤーピース コード長アジャスター(1)
- Fャリングケース(1) 取扱説明書(1)
- ソニーご相談窓口のご案内(1)

IISR 充電 AC 電源アダプター: AC-U501AD (別売)

バッテリー内蔵 USB AC チャージャー: AC-UP100 (別売)

*2 当社規定の航空機シミュレートノイズ下における、ノイズキャン zリングモード A 時と、ヘッドホンの非装着時との比較による 値です。総騒音抑制量約 16dB は音のエネルギーで約 97.5 % の

*4 日本及び一部の国でのみ販売 USB 充電のパソコン推奨環境

• 下記環境を満たすすべてのパソコンで動作を保証するものではあ

自作パソコンは動作保証対象外です。

Mac OS X (バージョン 10.5 以降

- Windows® 7 (Home Premium / Professional / Ultimate / Starte
- Windows® XP (Service Pack 3 以降) (Home Edition / Professional / Media Center Edition 2004
- "ウォークマン"、"WALKMAN"、"WALKMAN" ロゴは、ソニー株 Windows および Windows Vista は、米国 Microsoft Corporatio

本機の仕様および外観は、改良のため予告なく変更することがあり

の米国およびその他の国における登録商標、または商標です。 Macintosh、Mac OS は、米国および他の国々で登録された Apple Inc. の商標です。

ますが、ご了承ください。

保証書とアフターサービス

- この製品には保証書が添付されていますので、お買い上
- げの際お受け取りください • 所定事項の記入および記載内容をお確かめのうえ、大切

保証期間中の修理は 保証書の記載内容に基づいて修理させていただきます。詳

保証期間経過後の修理は 修理によって機能が維持できる場合は、ご要望により有料修


部品の保有期間について

しくは保証書をご覧ください。


理させていただきます。


当社ではヘッドホンの補修用性能部品(製品の機能を維持 するために必要な部品)を、製造打ち切り後6年間保有し


に保存してください 充電池残量:ヘッドホンのビープ音でお知らせ • 保証期間は、お買い上げ日より 1 年間です。 • ノイズキャンセリング機能は、乗り物や空調などの主に低 充電池残量 ビープ音 アフターサービス い周波数帯域の騒音に対してもっとも効果を発揮します。 すべての音が打ち消されるわけではありません。 調子が悪いときはまずチェックを 2回*1 • 自動車、バスなどでご使用の場合、路面状況によっては ノイズが発生することがあります。 少ない 1 🗇 *1 この説明書をもう一度ご覧になってお調べください。 • 携帯電話の影響によりノイズが入ることがあります。この 残量がなくなったとき 長いビープ音(約2秒間)*2 それでも具合の悪いときは 場合は、携帯電話から本機を離してください。 *1 ヘッドホンの電源オフ時 お買い上げ店または添付の「ソニーご相談窓口のご案内」 取り扱い上のご注意 *2 同時に電源ランプが 30 秒間点滅。 にあるお近くのソニーサービス窓口にご相談ください。 ノイズキャンセリングモードの種類: ヘッドホ





G

















WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Features

• The control box-free design in-the-ear type digital noise canceling headphones. Micro size Balanced Armature type driver unit and power-saving integrated DNC processor use miniaturized

battery and circuit, which allow the control box-free • Newly developed Balanced Armature type driver unit and high efficiency MEMS microphone realized both small

body and outstanding noise canceling performance. • Digital noise canceling headphones with Sony's unique DNC Software Engine.

Creation of a high-precision canceling signal delivers outstanding noise canceling performance. • 20 hour long battery life by newly developed power-

saving Integrated DNC Processor. Allows you to use on a • Automatic AI (Artificial Intelligence) Noise Canceling

function. Automatic selection of the optimal noise canceling mode based on intelligent analysis of environmental ambient

• Digital equalizer delivers ideal frequency response and

high-quality music reproduction. • 3 sizes of noise isolation earbuds for effective attenuation

of ambient noise. (S, M, L) USB charge adaptor supplied.

Charge the headphones first

The headphones contain a rechargeable nickel-metal hydride battery. Because the battery was included in the package at the time of manufacture (as a convenience to the user), the remaining battery charge may be somewhat depleted by the time of purchase. Be sure to recharge it before use. For the recharging procedure, see "Charging the

Location and Function of Parts (see fig. A)

Headphones

1 Microphones

2 Earbuds

3 Power indicator (red)

Indicates operating status of headphones.

4 (power) button

5 Stereo mini plug (charging plug)

USB charge adaptor

6 USB plug cap

7 USB plug

8 Charging indicator (orange)

Indicates charging status 9 Charging jack

Charging the headphones (see fig. **B**)

The headphones contain a rechargeable nickel-metal hydride battery. Charge the battery before use.

1 Turn on a computer

2 Detach the USB plug cap from the USB charge adaptor, then connect the USB charge adaptor to the computer.

3 Plug the headphones securely into the charging jack of the USB charge adaptor matching the jack The charging indicator lights up in orange and

recharging starts. 4 After the charging indicator goes out, unplug the

headphones from the USB charge adaptor. 5 Disconnect the USB charge adaptor from the

computer, and attach the USB plug cap.

General charging and usage time Depending on the remaining battery status of the headphones, the supplied USB charge adaptor requires approx. 15 minutes to 4 hours to recharge.

Approx. charging time Approx. usage time*1 20 hours*3

 \star_1 At 1 kHz, sound pressure level 90 dB output

*2 Hours required to fully charge an empty battery $^{\star 3}$ Time stated above may vary, depending on the temperature or conditions of use.

♥ Tips• If you start charging while the headphones are turned on, the headphones

The headphones cannot be turned on while charging.
If you recharge the headphones by connecting to an AC outlet, use the separately-sold USB Charging AC Power Adaptor AC-U501AD / Built-in Battery USB AC Charger AC-UP100 (see "Recommended accessories"). or more information, refer to the operating instructions supplied with

If the headphones are malfunctioning, charging will not start and the charging indicator will flash. In this case, disconnect the unit from the connected device, and consult your place of purchase, or a Sony dealer.

How to use the supplied cord adjuster • Charge in an environmental temperature of between 0°C and 40°C (32°F and 104°F). Otherwise, the battery may not fully charge.

on the cord or it may break.

If you haven't used the headphones for a long time, the life of the rechargeable battery may become short. This will improve when you

repeat the charging and discharging process several times.

headphone plug to the USB charge adaptor directly.

(see fig. 🖪) Take the headphones off before charging. When unplugging the headphones, hold the cord by the plug. Do not pull

You can adjust the cord length by winding the cord onto the cord adjuster.

clip just a little.

the cord into the groove under the lever.

Notes on using on an airplane

dual jacks

• Take the headphones off when not in use.

(see fig. G)

carrying case.

stereo mini jacks of in-flight music services.

• Do not use the headphones when use of electronic

equipment is prohibited or when use of personal

headphones for in-flight music services is prohibited.

How to use the carrying case

Beep and indicator status

*1 When turning the headphones OFF.

canceling modes

— charging status

Charging malfunction

No sound

Troubleshooting

• Turn on the headphones.

Power does not turn on.

Charging cannot be done.

• Check the charging indicator lights up.

• Check that the computer is turned on.

directly connected; not via a USB hub.

"Recommended accessories".

• You may be using an adaptor other than the

Recharge the headphones.

USB charge adaptor.

firmly connected.

hibernation mode.

Current NC mode

NC mode A

NC mode B

NC mode C

Status

*2 The power indicator flashes for 30 seconds

Beep from the headphones — battery status

Power indicator of the headphones — noise

Charging indicator of the USB charge adaptor

• Check that the rechargeable battery is not depleted.

• Check the connection of the headphones and the AV

• Check that the connected AV equipment is turned on.

• Turn up the volume of the connected AV equipment.

• The headphones cannot be turned on while charging

Unplug the headphones from the USB charge adaptor.

Plug the headphones securely into the charging jack of the

• Check that the USB charge adaptor and the computer are

• Check that the USB charge adaptor and the computer are

recommended one. Use a USB AC adaptor specified in

 $\bullet\,$ If the charging indicator flashes, the headphones may be

device, and consult your place of purchase, or a Sony

malfunctioning. Disconnect the unit from the connected

• Check that the computer is not in standby, sleep or

1 time*1

1 long beep (2 seconds

Power indicator flashes

1 time per 5 seconds

2 times per 5 seconds

3 times per 5 seconds

Charging indicator

Fast flashes

(The cord can be wound to the cord adjuster up to 40 cm. If you wind more, the cord comes off from the cord adjuster

1 Wind the cord. 2 Push the cord into the slot hole to secure in place.

Do not wind the plug or split section of the cord, as it will

2 Put the cord into the groove under the lever.

• If you pull up the lever on the clip without holding the clip closed, or

holding the clip closed but opening the lever too much, you cannot put

Do not catch the cord on the projection of the clip or do not wedge it into the groove. It may damage the wires of the cord.

• Do not move the clip position with the cord attached. It may damage the

• The supplied plug adaptor can be connected to the dual or

stereo mini jacks

strain the cord and may cause a wire break.

 Do not store the headphones in hot places for a long time. When storing it for more than a year, charge the battery once a year to prevent over For system requirements for a computer that can charge the battery using USB, see "System requirements for battery charge using USB".

• Charging will not start if the extension cord is used. Connect the

How to attach the clip to the cord (see How to install the earbuds fig. 🖪) correctly (see fig. **C**) 1 Hold the clip closed, and pull up the lever on the

If the earbuds do not fit your ears correctly, the noise canceling effect will not be optimal. To optimize noise canceling and to enjoy better sound quality, change the earbuds to another size, or adjust the earbud position to fit your ears comfortably and snugly.

If the earbuds do not fit your ears, try another size. Confirm size of the earbuds by checking colour inside (see fig. If you change the earbuds, install them firmly on the headphones to prevent the earbud from detaching and

remaining in your ear. **Earbud sizes (inside colour)**

 \rightarrow

To detach an earbud (see fig. **G**-②)

While holding the headphone, twist and pull the earbud off.

If the earbud slips and cannot be detached, wrap it in a soft

To attach an earbud (see fig. C-③)

Push the parts inside of the earbud into the headphone until the projecting part of the headphone is fully covered.

 Prolonged use of the noise isolation earbuds may strain your ears due to their snug fit. If you experience discomfort in your ears, it is The pressure-relieving urethane cushion is extremely soft. Therefore, do

r detached from the earbuds, it will not take its correct position and th earbuds will lose their noise isolation function. • The pressure-relieving urethane cushion may deteriorate due to

not pinch or pull the urethane cushion. If the urethane cushion is broken

long-term storage or use. If the pressure-relieving power is lost and the urethane cushion becomes hard, the earbuds may lose their noise • Do not wash the noise isolation earbuds. Keep them dry, and avoid accumulation of water in the pressure-relieving urethane cushions. Not

doing so may cause early deterioration.

Listening to music (see fig. **D**)

1 Connect the headphones to the AV equipment.

2 Put on the headphones. Wear the earpiece marked (R) in your right ear and the one marked (L) (L) has a tactile dot for easy recognition)

in your left ear.

Adjust the earbud position to fit your ears snugly If you wear the headphones incorrectly, noise canceling

will not be effective. Adjust the earbud position to sit on your ears comfortably and fit your ears snugly

3 Press and hold the () (power) button for about 2

Beeps sound from the headphones and the power indicator flashes.

You may also hear a slight noise; however, this is operational noise of the Noise Canceling function and not a malfunction.

4 Turn on the power of the AV equipment.

After use

1 Press and hold the () (power) button for about 2

Beeps sound from the headphones and the power indicator lights up, and then the headphones turn off.

2 Take the headphones off slowly.

• You cannot hear sound from AV equipment when the headphones are

• The headphones are designed to fit closely in your ears. If the headphones are pressed hard while in use or taken off too quickly, they may damage your eardrum or elsewhere.

Remaining battery

If the power does not turn on, even after charging the headphones, the rechargeable battery may be damaged You can check the remaining battery charge, by the number of beeps when you turn the headphones off. For details, refer Consult your place of purchase or a Sony dealer in this

to "Beep and indicator status". When the battery becomes empty, beeps sound from the headphones for 2 seconds and the power indicator flashes for 30 seconds. Then the headphones will turn off automatically.

Automatic AI Noise Canceling

Automatic AI Noise Canceling is a function that automatically selects one of the noise canceling modes When the headphones are turned on, NC mode B is set. This function provides very effective automatic noise canceling by constantly analyzing ambient sound.

Noise canceling modes

The current noise canceling mode can be checked by the number of power indicator flashes. For details, refer to "Beep and indicator status".

NC Mode A Noise mainly in an airplane is effectively reduced. NC Mode B

Noise mainly in a bus or a train is effectively reduced. Noise mainly found in an office environment (PC, copier, air ventilation, etc.) is effectively reduced.

Noise characteristics vary over time. The headphones automatically select the appropriate noise canceling mode for the situation.

computer.

The unit cannot be recognized by a

• Check that the USB charge adaptor and the computer are

firmly connected. • Disconnect the USB charge adaptor from the computer

and connect again.

• Check that the USB charge adaptor and the computer are directly connected; not via a USB hub.

• There may be a problem with the connected USB port of the computer.

Connect to another USB port if it is available. • Try the USB connection procedure again in cases other

than those stated above. **Muffled sound**

• Turn down the volume of the connected AV equipment. Recharge the headphones.

The headphones do not operate properly.

• The headphones cannot be turned on while charging. Unplug the headphones from the USB charge adaptor to

• Recharge the headphones. If the power does not turn on, even after charging the headphones, the rechargeable battery may be damaged

Consult your place of purchase or a Sony dealer in this

Specifications

Closed, Balanced Armatur Balanced Armature Power handling capacity: Impedance: 820 Ω (at 1 kHz) Sensitivity: 106 dB*1 Frequency response: 5 Hz – 20,000 Hz Total Noise Suppression Ratio*2: Approx. 16 dB* Approx. 1.5 m OFC Litz cord, neck-chain

Gold-plated L-shaped stereo mini plug

Built-in nickel-metal hydride rechargeable battery

Approx. 6 g (without cord) **Included items**

Bundle the cord before storing the headphones in the USB charge adaptor (1) Plug adaptor for in-flight use*4 (single/dual) (1) Noise Isolation Earbuds (S \times 2, M \times 2, L \times 2) Cord adjuster (1)

Carrying case (1)

Operating Instructions (1) Warranty card (1) Recommended accessories (sold separately)* USB Charging AC Power Adaptor: AC-U501AD
Built-in Battery USB AC Charger: AC-UP100

*1 150 mV input

*2 Under the Sony measurement standard.

*3 Equivalent to approx. 97.5 % reduction of energy of sound compared with not wearing headphones

*4 May not be compatible with some in-flight music services. *5 Sold in Japan and some other countries

System requirements for battery charge using USB

Personal Computer with pre-installed with any of the following operating systems and USB port: Operating Systems

 When using Windows* Windows® 7

(Home Premium / Professional / Ultimate / Starter) (including 64 bit version) Windows Vista® (Service Pack 2 or later) (Home Basic / Home Premium / Business / Ultimate) (including 64 bit version) Windows* XP (Service Pack 3 or later) (Home Edition / Professional / Media Center Edition

2004 / Media Center Edition 2005)

• When using Macintosh Mac OS X (version.10.5 or later)

Windows and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or Macintosh and Mac OS are trademarks of Apple Inc., registered in the

Design and specifications are subject to change without notice

Precautions

mobile phone.

The headphones contain a noise canceling circuit.

What is noise canceling?

The noise canceling circuit actually senses outside noise with built-in microphones and sends an equal-but-opposite canceling signal to the headphones.

• The noise canceling effect may not be pronounced in a very quiet environment, or some noise may be heard. • Do not cover the microphones of the headphones with your hands. The noise canceling function may not work

• The noise canceling effect may vary depending on how you wear the headphones. • The noise canceling function works for noise in the low frequency band primarily. Although noise is reduced, it is

this occur, locate the headphones further away from the

not canceled completely. • When you use the headphones in a train or a car, noise may occur depending on street conditions. • Mobile phones may cause interference and noise. Should

• Clean the headphones with a soft dry cloth.

- Do not leave the jack plug dirty otherwise the sound may
- Be sure to bring the headphones to a Sony dealer when
- direct sunlight, heat or moisture. • Do not subject the headphones to excessive shock.
- The earbuds will need to be replaced from time to time. If they are worn out by daily use or longtime storage, replace
- If you fell drowsy or sick while using these headphones,
- Store the earbuds where children cannot reach in order to

Notes on headphones

Do not use headphones while driving or cycling,

As headphones reduce outside sounds, they may cause a

Note on static electricity

Notes on usage

- requiring a change of earbuds or repair work.

- Do not leave the headphones in a location subject to
- them with new ones.
- stop use immediately. • The headphones are designed to fit closely in your ears. If the headphones are pressed hard while in use, they may damage your eardrum or elsewhere. Do not use the headphones in a crowd or a place where a ball, etc., may
- Install the earbuds firmly onto the headphones. If an earbud accidentally detaches and is left in your ear, it may
- prevent from accidental ingestion or choking.

Preventing hearing damage advise against continuous, loud and extended play. If you experience a ringing in your ears, reduce the volume or discontinue use.

traffic accident. Also, avoid listening with your headphones in situations where hearing must not be impaired, for example, a railroad crossing, a construction site, etc.

natural materials.

In particularly dry air conditions, noise or sound skipping may occur, or mild tingling may be felt on your ears. This is a result of static electricity accumulated in the body, and not a malfunction of the headphones. The effect can be minimized by wearing clothes made from

If you have any questions or problems concerning the ystem that are not covered in this manual, please consult your nearest Sony dealer.